

Update GEWA UP-pianos (UP260 / UP280 / UP280WK)

Which firmware is installed on your piano:

- press: "Menu" - "General Settings" - "Piano Information"
- compare the current firmware on our homepage with the installed firmware on your piano
- if this firmware is already installed, no further steps are necessary
- if an older version is displayed on your piano, please update the instrument as follows:

Installation:

1. after downloading the current firmware, connect the USB stick to the instrument
2. switch on the piano; while keeping sub-contra-A and contra-cis pressed. (see fig. 1)
3. press the cursor keys to select the file to install
4. confirm / install selected file by cursor arrow "Left". (see fig. 2)
5. switch off the piano (hold "Power" for approx. 6 sec.) and switch it on again

duration of installation :

- approx. 20 seconds

